part of Devon & Cornwall Housing group

Are there any obvious signs that a gas appliance may be dangerous?

Your gas appliance may be unsafe if you notice any of the following signs:

- a yellow or orange flame instead of a blue one
- a pilot light which keeps blowing out
- any part of the appliance has turned black or brown, or shows signs of scorching
- signs of soot, a sooty or musty smell
- increased condensation on windows

- Up to Repairs
- Next: What should I do if I suspect a gas appliance is dangerous?

©2012 Penwith Housing Association
Built on Cubik

Sign In